











If your A/C brand is not listed follow

Step 12

Step 11.





Step 12.

Carefully read the 'Auto Search Code Setting' section

Step 13.

Ensure the Code Set Up function is unlocked. See Step 5

Step 14.

Aim the Smart Remote at your A/C & press "Select" key for about 5 seconds this will turn on 'Auto Search' function

Step 15.

The Remote will emit a continuous signal to the A/C & the Code numbers on the LCD will flash & increase steadily

Keep the remote pointing at the A/C at all times

Step 16.

When the A/C receives a signal it recognises, the A/C will beep.

IMMEDIATELY

IMMEDIATELY PUSH ANY KEY

To stop the search on the Code that made the A/C beep.

do Saarch Code Salling

If you do not know the brand of your air conditioner or if your brand is not listed in the cool

1. Enouge the Code Set Up Function is unlooked. If necessary unlock the "Code Set Up

2. Am the Drant Termite of your an conditioner Press and hold the "SQUECT" key for 5 seconds and their relation, the Smart Remote will go into auto-search mode and will ent a continuous signal. The code numbers on the LCD with fash and steady increase, if the code numbers start for right, one the previous AC Code Get by instructions to mod the code that the Auto-Search will shart from, lithher the AC receives the correct signal if will make a beep, immediately press any key to confirm.







Step 17.

Then test this Code by pointing the remote at the A/C & pressing the blue power button on & off.

If it turns the A/C on & off check all functions. If the A/C does not turn on or off or if any of the functions don't work correctly, this means it's not the correct code

Step 18.

Turn the 'Auto Search' back on

*Step 14

From Step 14 follow instructions
through till Step 17 again. Until
all functions are working correctly

Step 19.

Once the Code is proven to be correct & working Press the "Enter OK" key once to lock it in

Step 20.

This process can be repeated as many times as required until the correct Code is found & all functions are working correctly



www.airconoff.com.au





Please Note:

At any time
(especially when changing batteries).
If the remote does
not wake up or the screen is blank.
Reboot the remote by taking the
existing or new batteries out &
then put them back in one more time



Push the Reset Button by using a fine tip pen or other sharp object

Reset **will not** effect your memory setup



